

EXTREME MARQUEES

CAR AWNING RANGE

DESERT SHADE 90°

INSTRUCTION MANUAL



SET-UP INSTRUCTIONS



STEP 1.

Before begin the set-up, ensure the area around the car awning is clear from trees and any other hazards.



STEP 2.

Installation requires 2 people. Begin by unzipping the car awning protective cover bag.



STEP 3.

Undo the three Velcro straps around the car awning. Roll down the fabric/frame.



STEP 4.

Person one needs to support the awning while person two completes steps 5 & 6.



STEP 5.

Person two can now unfold the two roof arms from the awning bracket.



STEP 6.

The roof arms can be adjusted in length by twisting them at the joint. Extend these to the same length as the awning fabric.



STEP 7.

Loop the bottom of the roof arm through the whole in the awning frame to secure. Attach the Velcro straps from fabric around the arm.



STEP 8.

Lower both legs from the awning frame. Adjust to desirable height by twisting legs at the joint.



STEP 9.

Secure the awning to the ground using the two tie-down straps and steel pins.



EXTREME MARQUEES

CAR AWNING RANGE

DESERT SHADE 90°

INSTRUCTION MANUAL

PACK-DOWN INSTRUCTIONS



STEP 1.

Take off the two tie-down straps and pins from the awning and fold up the two support legs back into the awning frame.



STEP 2.

Person one can start to undo the Velcro from the two awning arms while person two supports the awning.



STEP 3.

Person two can then shorten the awning arms and fold them back into the awning bracket.



STEP 4.

Tightly roll up the car awning fabric into the protective cover.



STEP 5.

Once the fabric is rolled up, secure with the two Velcro straps and tuck the tie-down ropes into the bag.



STEP 6.

Zip the protective cover bag closed.

NEVER TRAVEL WITH AWNING OR AWNING BAG OPEN.